

**PM6-FX**  
Ratemeter  
Process Monitor  
Operation and Instruction Manual

---

---

# Table of Contents

---

<b>Introduction</b> . . . . .	<b>1</b>
<b>Mechanical Installation</b> . . . . .	<b>2</b>
<b>Electrical Installation</b> . . . . .	<b>3</b>
Display hold switch . . . . .	4
Transducer power supply . . . . .	4
Connection details . . . . .	4
Hysteresis link settings . . . . .	5
Input circuit . . . . .	5
Input connection details . . . . .	6
Configuring the input board . . . . .	8
Input configuration . . . . .	9
<b>Explanation of Functions</b> . . . . .	<b>10</b>
Setup examples . . . . .	12
Error Messages . . . . .	13
<b>Function Table</b> . . . . .	<b>14</b>
<b>Specifications</b> . . . . .	<b>15</b>
<b>Guarantee and Service</b> . . . . .	<b>16</b>

---

# 1 Introduction

---

This manual contains information for the installation and operation of the PM6 monitor. The PM6 is a general purpose rate/frequency monitor which may be configured to accept inputs within the range of 0 to 10KHz. The instrument may be push button calibrated/scaled to display the input, directly in frequency or in engineering units.




Unless otherwise specified at the time of order, your PM6 has been factory set to a standard configuration. Like all other PM6 series instruments the configuration and calibration is easily changed by the user. Initial changes may require dismantling the instrument to alter PCB links, other changes are made by push button functions. The FREQ and SCLE functions are used to scale the instruments to the required display units.

The PM6 series of Panel Mount Monitors are designed for high reliability in industrial applications. The high brightness 4 digit LED display provides good visibility, even in areas with high ambient light levels.



## 2 Mechanical Installation


The dimensions of the PM6 are shown in the diagrams below. The panel cut out required to mount the PM6 is 45mm x 92mm as shown below. The tolerances on this cut out are +1mm/-0mm. Insert the panel meter from the front of the panel. From the rear of the instrument place the two mounting brackets into the side recesses. Whilst holding the brackets (the elastic bands provided may prove useful for this) tighten the securing screws. Be careful not to over tighten the screws as this could cause damage to the instrument casing.



### 3 Electrical Installation

The PM6-FX Panel Meter is designed for continuous operation and no power switch is fitted to the unit. It is recommended that an external switch and fuse be provided to allow the unit to be removed for servicing.

The terminal blocks, which are the plug in type for ease of installation, allow for wires of up to 2.5mm to be fitted. Connect the wires to the appropriate terminals (examples shown below). Since various output options are available refer to the data label on the actual instrument being installed for exact connection details. Refer to other details provided in this chapter to confirm proper selection of voltage, polarity and input type before applying power to the instrument. It is recommended that shielded cable is used for the signal input. When power is applied the instrument will cycle through a display sequence, indicating the software version and other status information, this indicates that the instrument is functioning.




Instrument Rear Panel

1	MAINS EARTH	
2	240VAC NEUTRAL	
3	240VAC ACTIVE	
5	DC OUTPUT	GND
6	DC OUTPUT	+24V
7	DISPLAY HOLD	
8	GROUND	
9		
10	DC OUTPUT	+5V
11	SIGNAL INPUT	
PM6-FX-240-4E		SERIAL No:

Instrument Data Label (example)


### 3.1 Display hold switch

The display hold switch contacts are placed across terminals 7 and 8 at the rear of the PM6. The display will be held whilst the contact is closed and will return to normal measurement when the contact is opened.




### 3.2 Transducer power supply

A standard transmitter supply of 5VDC (regulated) is provided on all models. An 18 to 24VDC (unregulated) transmitter supply is provided on AC isolated DC powered models. Only one transmitter supply should be used at any one time. The transmitter supplies are rated at 20mA.



### 3.3 Connection details




### 3.4 Hysteresis link settings

Two hysteresis links are used to optimise the input circuit gain.


Signal voltage	Link 10 (HYST 1)	Link 11 (HYST 2)
Input signal above 2.5V	IN	OUT
Input signal above 100mV	OUT	IN
Input signal above 20mV	OUT	OUT

### 3.5 Input circuit




### 3.6 Input connection details


#### INDUCTIVE SENSOR




#### AC MEASUREMENT




#### SQUARE WAVE INPUT



#### CONTACT CLOSURE



#### NAMUR SENSOR



#### Inductive Sensor (48V RMS Max)

##### Typical Internal Link Settings

- Low frequency Link 5 . . . . . out
- VCC up . . . . . Link 6 . . . . . out
- Ground . . . . . Link 7 . . . . . see notes
- DC couple. . . . . Link 8 . . . . . in
- Supply V+ . . . . . n/a
- Bias . . . . . Link 9 . . . . . out
- Hysteresis. . . . . Links 10 & 11. see notes

Notes: Ground link should be out if input is greater than 48V. See section 3.4 for hysteresis link settings.

#### AC Measurement (48V RMS Max)

##### Typical Internal Link Settings

- Low frequency Link 5 . . . . . out
- VCC up . . . . . Link 6 . . . . . out
- Ground . . . . . Link 7 . . . . . see notes
- DC couple. . . . . Link 8 . . . . . see notes
- Bias . . . . . Link 9 . . . . . out
- Hysteresis. . . . . Links 10 & 11. see notes
- Supply V+ . . . . . n/a

Notes: Ground link should be out if input is greater than 48V. The DC coupling link should be in for frequencies less than 10Hz. See section 3.4 for hysteresis link settings.

#### Square Wave (48V Max)

##### Typical Internal Link Settings

- Low frequency Link 5 . . . . . out
- VCC up . . . . . Link 6 . . . . . out
- Ground . . . . . Link 7 . . . . . see notes
- DC couple. . . . . Link 8 . . . . . in
- Bias . . . . . Link 9 . . . . . see notes
- Hysteresis. . . . . Links 10 & 11. see notes
- Supply V+ . . . . . n/a

Notes: Ground link should be out if input is greater than 48V. The bias link should be in when input signal does not go below 0V. See section 3.4 for hysteresis link settings.

#### Switch Contact

##### Typical Internal Link Settings

- Low frequency Link 5 . . . . . in
- VCC up . . . . . Link 6 . . . . . in
- Ground . . . . . Link 7 . . . . . out
- DC couple. . . . . Link 8 . . . . . in
- Bias . . . . . Link 9 . . . . . in
- Hysteresis. . . . . Link 10 . . . . . in
- Hysteresis . . . . . Link 11 . . . . . out
- Supply V+ . . . . . n/a

#### NAMUR Sensor

##### Typical Internal Link Settings

- Low frequency Link 5 . . . . . out
- VCC up . . . . . Link 6 . . . . . out
- Ground . . . . . Link 7 . . . . . in
- DC couple. . . . . Link 8 . . . . . in
- Bias . . . . . Link 9 . . . . . in
- Hysteresis. . . . . Link 10 . . . . . in
- Hysteresis. . . . . Link 11 . . . . . out


**General Note:**

This alternative earthing method may be used when noisy signals are present. This method should only be used when the shield is disconnected externally.

Add link between 1 & 8 (input ground & earth)



**NPN TRANSISTOR**




**NPN Transistor**

Typical Internal Link Settings

Low frequency	Link 5 . . . . .	out
VCC up	Link 6 . . . . .	in
Ground	Link 7 . . . . .	out
DC couple.	Link 8 . . . . .	in
Bias	Link 9 . . . . .	in
Hysteresis.	Link 10 . . . . .	in
Hysteresis	Link 11 . . . . .	out
Supply V+	. . . . .	see note

Note: The transducer may require an external DC supply. This may be provided from a remote power source or by a +18V unregulated DC output on terminal 6 or the 5VDC regulated output on terminal 10 (see section 3.2 “Transducer Power Supply”).

**NPN TRANSISTOR  
3 WIRE**




**NPN Transistor 3 Wire**

Typical Internal Link Settings

Low frequency	Link 5 . . . . .	out
VCC up	Link 6 . . . . .	in
Ground	Link 7 . . . . .	out
DC couple.	Link 8 . . . . .	in
Bias	Link 9 . . . . .	in
Hysteresis.	Link 10 . . . . .	in
Hysteresis.	Link 11 . . . . .	out
Supply V+	. . . . .	see note

Note: The transducer may require an external DC supply. This may be provided from a remote power source or by a +18V unregulated DC output on terminal 6 or the 5VDC regulated output on terminal 10 (see section 3.2 “Transducer Power Supply”).

**PNP TRANSISTOR**




**PNP Transistor**

Typical Internal Link Settings

Low frequency	Link 5 . . . . .	out
VCC up	Link 6 . . . . .	out
Ground	Link 7 . . . . .	in
DC couple.	Link 8 . . . . .	in
Bias	Link 9 . . . . .	in
Hysteresis.	Link 10 . . . . .	in
Hysteresis.	Link 11 . . . . .	out
Supply V+	. . . . .	see note

Note: The transducer may require an external DC supply. This may be provided from a remote power source or by a +18V unregulated DC output on terminal 6 or the 5VDC regulated output on terminal 10 (see section 3.2 “Transducer Power Supply”).

**PNP TRANSISTOR  
3 WIRE**



**PNP Transistor 3 Wire**

Typical Internal Link Settings

Low frequency	Link 5 . . . . .	out
VCC up	Link 6 . . . . .	out
Ground	Link 7 . . . . .	in
DC couple.	Link 8 . . . . .	in
Bias	Link 9 . . . . .	in
Hysteresis.	Link 10 . . . . .	in
Hysteresis.	Link 11 . . . . .	out
Supply V+	. . . . .	see note


Note: The transducer may require an external DC supply. This may be provided from a remote power source or by a +18V unregulated DC output on terminal 6 or the 5VDC regulated output on terminal 10 (see 3.2 “Transducer Power Supply”).

### 3.7 Configuring the input board

#### Selecting the input

Dismantle the instrument as described in section 3.8 “Input/output configuration”. Insert the links into the appropriate location on the pin header, to suit the application or input sensor.


#### Input Configuration Selector Links (see input connection details for required combinations)




### 3.8 Input configuration

The procedure below illustrates how to dismantle the instrument to make any changes required to link settings. This procedure may be required when initially setting up the instrument or if the sensor type is changed.


**1. Remove the plug in terminals from the rear of the instrument**



**2. Remove 4 x self tapping screws from back cover, remove back cover by pulling it away from the instrument**



**3. Using a screwdriver, loosen the earth screw which passes through the aluminium case then slide out the board.**



**4. Configure the PCB links as required, see section 3.4**

**5. Slide PCB back into the case**

**6. Re tighten the earth screw which passes through the PCB**

**7. Refit back cover and fix with the self tapping screws**

**8. Plug the terminal strips back into the rear of the instrument**


## 4 Explanation of Functions

The PM6 setup and scaling functions are configured through a pushbutton sequence. To enter the function set up mode, a simple pushbutton sequence is necessary (this prevents accidental alteration of settings). The process is as shown below:

Functions may be accessed by pressing and releasing the **F** pushbutton to step through the functions. Once the required function is reached changes can be made via the **▲** or **▼** buttons.



1. With the display switched on and showing its normal reading press, then release the **F** button.



2. Within 2 seconds of releasing the **F** button press, then release the **▲** and **▼** buttons together. The display will now indicate **FUNC** followed by the first function.

Functions available in this instrument are:

### **br 9t (display brightness)**

Displays and sets the digital display brightness. The display brightness is selectable from **0** to **15**, where **0** = lowest intensity and **15** = highest intensity. This function is useful for reducing glare in low light environments.

### **dr nd (display rounding)**

Displays and sets the display rounding value. This value may be set to 0 - 5000 displayed units. Display rounding is useful for reducing the instrument resolution in the set up mode, allowing the display to change larger steps for faster setting of setpoints etc.

### **dCPt (decimal point selection)**

Displays and sets the decimal point. By pressing the **▲** or **▼** pushbuttons the decimal point position may be set. The display will indicate as follows: **0** (no decimal point), **0. 1** (1 decimal place), **0.02** (2 decimal places), **0.003** (3 decimal places).

Note: Changes to the decimal point will affect the existing display scaling. If the decimal point place is changed then the display may need to be rescaled (see **FfEQ** and **SCLE** functions).

### **FLtR (digital filter)**

Displays and sets the digital filter value. Digital filtering is used for reducing susceptibility to short term interference. The digital filter range is selectable from **0** to **8**, where **0** = none and **8** = most filtering. A typical value for the digital filter would be **3**.

### **Lf n9 (measuring range lower limit)**

Displays and sets the lowest accepted input frequency. This function is normally set to **0** where the lowest displayable frequency is 2Hz. For low rate applications a lower frequency limit may be selected:

**1** = 1 Hz, **2** = 0.5Hz and **3** = 0.25Hz.

Note: settings **1** to **3** will decrease the display update rate.

### **FfEQ (input frequency, used with scaling factor)**

Scaling the PM6-FX involves entering the ratio between the input frequency and the scaling factor. The displayed value will indicate the **SCLE** number when the input is at this frequency.

The equation used is as follows:

$$\text{Display value} = \frac{\text{Input Frequency (Hz)} \times \text{"SCLE "}}{\text{"FREQ "}}$$

This allows the PM6-FX to be scaled in Bottles/min., R.P.M. etc.

For example: if the input is 50Hz and this corresponds to 3000 R.P.M., **FREQ** would be entered as **50** and **SCALE** as **3000**

Note: since these factors are entered as a ratio, they may be entered as the lowest common denominator. i.e.: in the above example **FREQ** may be entered as **1** and **SCALE** entered as **60**.

See “Setup examples” later in this chapter for further scaling examples.

### **SCALE (scaling factor)**

The scaling factor is used with the **FREQ** factor to produce a scaled display. See “Setup examples” later in this chapter for scaling examples.

### **dbLo (display blanking low)**

Displays and sets the display blanking low frequency. If the scaled display reading falls below the **dbLo** figure then the display will blank. This function may be disabled by pressing the **▲** and **▼** buttons simultaneously, the display will then show **OFF**.

### **dbHi (display blanking high)**

Displays and sets the display blanking high frequency. If the scaled display reading goes above the **dbHi** figure then the display will blank. This function may be disabled by pressing the **▲** and **▼** buttons simultaneously, the display will then show **OFF**.

## **4.1 Setup examples**

### **Example 1 - Changing the digital filter setting.**

1. Press, then release, the **F** button. Within 2 seconds of releasing the **F** button press the **▲** and **▼** buttons simultaneously. The display will indicate **FUNC** followed by the first function **brgt**.
2. Press, and release, the **F** button to step through the functions until the function **FLtr** appears followed by the last setting in memory.
3. Use the **▲** or **▼** button to alter the filter setting as required. Press the **F** button to accept the change.
4. Press, and release, the **F** button repeatedly until the message **FUNC End** appears and the display returns to its normal measurement mode.

### **Example 2 - Display scaling**

The PM6-FX is connected to a flowmeter which gives out 40 pulses for every 1.5 litres of water passing through a pipe. The display is to be scaled to read in litres per hour.

1. Press, then release, the **F** button. Within 2 seconds of releasing the **F** button press the **▲** and **▼** buttons simultaneously. The display will indicate **FUNC** followed by the first function **brgt**.
2. Press, and release, the **F** button to step through the functions until the function **FREQ** appears. The display will show the last frequency factor in memory and **FREQ** will flash approximately once every 8 seconds.
3. Use the **▲** or **▼** button to adjust the frequency factor to **40** then press the **F** button to accept this change.
4. The display will now show **SCALE** followed by the scaling factor in memory. Use the **▲** or **▼** button to change the scale factor to **5400**. The scale factor is 1.5 x 3600 where 1.5 is the number of litres per 40 pulses and the 3600 (60 seconds x 60 minutes) converts this to litres/hour.
5. Press, and release, the **F** button repeatedly until the message **FUNC End** appears and the display returns to its normal measurement mode.

Note that since the **FREQ** and **SCALE** factors are actually used as ratios in calculating the display values then a **FREQ** setting of **1** and a **SCALE** setting of **135** would give the same result.

### **Example 3 - Display scaling**

The PM6-FX is connected to a proximity detector which gives out 6 pulses for every revolution of a shaft. The display is to be scaled to read in revolutions per minute (R.P.M.).

1. Press, then release, the **F** button. Within 2 seconds of releasing the **F** button press the **▲** and **▼** buttons simultaneously. The display will indicate **FUNC** followed by the first function **brgt**.
2. Press, and release, the **F** button to step through the functions until the function **FREQ** appears. The display will show the last frequency factor in memory and **FREQ** will flash approximately once every 8 seconds.

3. Use the **▲** or **▼** button to adjust the frequency factor to **5** then press the **F** button to accept this change.

4. The display will now show **SCALE** followed by the scaling factor in memory. Use the **▲** or **▼** button to change the scale factor to **50**. The factor 60 is used to convert the display from a “per second” display to a “per minute” display i.e. there are 60 seconds in one minute.

5. Press, and release, the **F** button repeatedly until the message **FUNC End** appears and the display returns to its normal measurement mode.

Note that since the **FREQ** and **SCALE** factors are actually used as ratios in calculating the display values then a **FREQ** setting of **1** and a **SCALE** setting of **10** would give the same result.

## 4.2 Error Messages

**-or-**

Indicates an overrange error on the rate display i.e. the rate indication has gone beyond **9999** or **9999** etc. Check the maximum rate value to be displayed, the PM6 cannot display a value beyond **9999**. If decimal points are being used then reducing the number of decimal point places may cure the problem.

If the maximum rate is not a problem but the display is still displaying **-or-** then it is possible that the panel meter is experiencing interference and is measuring the rate of this interference. Check that the internal links are set to suit the input type being used (see chapter 3 for details) especially check the settings of the hysteresis links. If the interference is above 1kHz and the signal is below 1kHz then inserting the “FREQ” link may help to filter out the interference. Increasing the value of the digital filter function **FLTR** may also help to reduce the effect of interference on the display. Ensure that screened signal cables are used (see chapter 3 for examples of shield connection). Also ensure that signal cables are not placed next to cables likely to radiate interference e.g. power cables.

### Display is blank.

First check that the blanking functions (**dbLo** and **dbHi**) to ensure that they are not causing the display blanking.

A completely blank display indicates a hardware failure normally a power supply failure. DC powered instruments are fitted with a self healing fuse. If you are using a DC powered instrument then remove power for 3 or 4 minutes and then try re powering. Check to see that power is reaching the instrument. If power is reaching the instrument and the display is still completely blank i.e. not even displaying **0** then the instrument will need to be returned to supplier for repair.

## 4.3 Function table

Initial display	Meaning of display	Next display	Default Setting	Record Your Settings
<b>brgt</b>	Display brightness	<b>1</b> to <b>15</b>	<b>15</b>	
<b>drnd</b>	Display rounding selects resolution	Value in memory	<b>1</b>	
<b>dCpt</b>	Display decimal point	Decimal point position (e.g. <b>0</b> , <b>0.10.02</b> etc.)	<b>0</b>	
<b>FLTR</b>	Digital filter range 0 to 8	<b>0</b> to <b>8</b> ( <b>8</b> =most filtering)	<b>3</b>	
<b>LRNG</b>	Low measuring range	<b>0</b> , <b>1</b> , <b>2</b> or <b>3</b>	<b>0</b>	
<b>FREQ</b>	Frequency input factor	Value in memory	<b>1</b>	
<b>SCALE</b>	Display scale factor	Value in memory	<b>1</b>	
<b>dbLo</b>	Display blanking low value	Value in memory	<b>OFF</b>	
<b>dbHi</b>	Display blanking high value	Value in memory	<b>OFF</b>	

---

## 5 Specifications

---

### Technical Specifications

Input Types:	Selectable types including NPN, PNP, switch contact, magnetic pickup, TTL, CMOS etc.
Frequency range:	10kHz max, 0.25Hz min.
Impedance:	10K $\Omega$
Sample Rate:	4/sec nominal (1/sec on low frequencies)
Measurement Method:	Reciprocal time period technique
Microprocessor:	MC1468HC05 CMOS
Ambient Temperature:	-10 to 60°C
Humidity:	5 to 95% non condensing
Display:	4 digit, 20mm LED
Transducer Power:	+5VDC regulated or 18-24VDC unregulated
Power Supply:	AC 240V, 110V, 24V 50/60Hz DC non isolated 12 to 24V or optional isolated DC 9 to 55V
Power Consumption:	AC supply 2 VA + transmitter current, DC supply 2W + transmitter current

### Physical Characteristics

Bezel Size:	DIN 48mm x 96mm x 10mm
Case Size:	44mm x 91mm x 120mm behind face of panel
Panel Cut Out:	45mm x 92mm +1mm &- 0mm
Connections:	Plug in screw terminals (max 2.5mm wire)
Weight:	400 gms approx.

---

## **6 Guarantee and Service**

---

The product supplied with this manual is guaranteed against faulty workmanship for a period of 2 years from the date of dispatch.

Our obligation assumed under this guarantee is limited to the replacement of parts which, by our examination, are proved to be defective and have not been misused, carelessly handled, defaced or damaged due to incorrect installation. This guarantee is VOID where the unit has been opened, tampered with or if repairs have been made or attempted by anyone except an authorised representative of the manufacturing company.

Products for attention under guarantee (unless otherwise agreed) **must be returned to the manufacturer freight paid** and, if accepted for free repair, will be returned to the customers address in Australia free of charge.

When returning the product for service or repair a full description of the fault and the mode of operation used when the product failed must be given.

In any event the manufacturer has no other obligation or liability beyond replacement or repair of this product.

Modifications may be made to any existing or future models of the unit as it may deem necessary without incurring any obligation to incorporate such modifications in units previously sold or to which this guarantee may relate.

**This document is the property of  
the instrument manufacturer  
and may not be reproduced in whole or part without the  
written consent of the manufacturer.**

**This product is designed and manufactured in Australia.**



